



# Uni DMX controls and accessories

## ZXP399 main controller DMX/RDM

Uni DMX controls and accessories, 90 to 264 V, 50 to 60 Hz, 50 to 60 Hz, Finger-protected, CE mark, Black

The ZXP399 DMX Controls and Wiring Accessories are to be used with our architectural and facade lighting luminaires (UniFlood C, M and G, UniStrip G4, UniEdge, UniDot G2, UniString and UniBar). DMX Controls include main controller, stand-alone controller, sub-controllers, DMX amplifier and DMX addressing device. Main Controller: Industrial computer that can control up to 6000 DMX universes. Stand-alone Controller: Fits for medium applications with up to 700 DMX universes. Wiring accessories include leader and jumper cables with male and female IP67 connectors and end-caps. Addressing Device: Hand-held device that can write DMX addresses to a whole run on-site within minutes. DMX Amplifier: Compact, IP65 and low power repeater that can amplify the DMX signal for up to 100 meters.

### Product data

General Information		Dimensions (Height x Width x Depth)	
Accessory color	Black		177 x 361 x 482 mm
Operating and Electrical		Approval and Application	
Input Voltage	90 to 264 V	Ingress protection code	IP20 [Finger-protected]
Line Frequency	50 to 60 Hz	CE mark	CE mark
Mechanical and Housing		Product Data	
Overall length	482 mm	Full product code	871951494686600
Overall width	361 mm	Order product name	ZXP399 main controller DMX/RDM
Overall height	177 mm	Order code	911401756622
		Numerator - Quantity Per Pack	1

## Uni DMX controls and accessories

Numerator - Packs per outer box	1
Material Nr. (12NC)	911401756622
Full product name	ZXP399 main controller DMX/RDM

EAN/UPC - Case	8719514946866
----------------	---------------

### Dimensional drawing

